


# RHÖNBUSSARD

1/4 SCALE  
 DESIGNED, DRAWN, INKED  
 BY  
 QUINN E. ...  
 3/80, 5/80, 2/82



THE FUSELAGE CAN BE COVERED WITH "COVERITE" OR "GLASSKOTE" OR JUST COVERED WITH GLASSKOTE.

1/2" SHEET HARD Balsa OR SPRUCE TAIL SKID CAN BE CAPPED WITH BRASS SKID

4 PCS OF 1/32" x 1/8" PLYWOOD LAMINATED TO THE INSIDE OF THE TAIL IN THE SHAPE OF THE T.E.

1/4" x 1/2" Balsa L.E.

RUBBER TRAVEL ± 2"

1/2" x 1/2" Balsa RIDDER SPAR

1/2" x 1/4" Balsa FIN SPAR

NOTCH KEEL FOR STAB BLOCK

EPXY THE ATTACHMENT AREA OF STAB AND FUSE

RUBBER CONTROL HORN WITH 1/4" BOLT

3/16" x 3/8" SPRUCE KEEL

ELEVATOR PUSH ROD

RUBBER PUSH ROD

3/16" x 3/8" SPRUCE KEEL

1/8" OR 3/32" Balsa SIDES

SPRICE BLOCK

Balsa BLOCK

2" x 2" Balsa BLOCK CAPED TO SHAPE (EPXY)

1/8" PLYWOOD RIB FAIRING

3/16" Balsa BLOCK NOTCHED FOR SPRUCE KEEL (EPXY)

1/4" I.D. FIBERGLASS WING ROD TUBE

EPXY HING ROD TUBE TO Balsa BLOCK IF YOU WISH

3/8" SPRUCE BLOCK (EPXY)

1/8" PLYWOOD HATCH TRAY

CURTAIN HOOK-TOW HOOK PAINTED ON SIDE, THIS CAN BE USED WITH A BRITTLE

1/4" PCS OF CAR BAC HOSE FOR SHOCK ABSORBERS

SPRUCE TOW HOOK BLOCK

BRASS BRACKETS AND BOLTS

2 PCS 1/16" PLYWOOD LAMINATED WITH "HOTSTUFF"

ALL FORMERS 1/8" OR 3/32" PLYWOOD

ALTERNATE SERVO

